

Download Lynx Plus Programming Manual

5800 Series Transmitter Loop Numbers Diagram21 Lynx Plus Summary of Connections Diagram.....23
Refer to the Lynx Plus Series Installation and Setup Guide P/N 800-03858 or later for detailed information on programming the system. The Installation and Setup Guide contains full descriptions for all data fields. Lynx Plus Security System Programming Guide BYPASS NO DELAY RECORD TEST STATUS FUNCTION VOLUME PLAY CODE LIGHTS ON LIGHTS OFF CHIME ESCAPE ADD DELETE SELECT OFF 132 STAY AWAY 4 5 6 AUX ARMED READY 7 8 9 0 800-03859 9/09 Rev. A View online Programming manual for Honeywell Lynx Plus Series Security System or simply click Download button to examine the Honeywell Lynx Plus Series guidelines offline on your desktop or laptop computer. Lynx Plus Series Installation and Setup Guide - 5 - System Features The Lynx Plus Series control is a self-contained, rechargeable wireless control/communicator that features easy installation and usage. A built-in speaker provides voice annunciation of system status along with voice descriptors of each zone.